

INSTALLATION INSTRUCTIONS

For Models #P5746-084

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.
AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.

HANGING THE FIXTURE (Fig. 1)

1. Carefully remove the fixture from the carton and check that all parts are included as shown in the illustration.
2. Shut off power at the circuit breaker and remove old fixture including the crossbar.
3. Determine desired distance from ceiling to hang the fixture, Install the **Strain Relief Bushing (A)** by bushing the cord through the holes until about 6" of cord is exposed. The fixture can now hang from the strain relief.
4. Attach the **Crossbar (B)** to the Outlet box in the ceiling with two outlet box **Screws (C)**. The side of the Bracket with "GND" marked on it and two convex points must face out.

CONNECTING THE WIRES (Fig. 2)

5. At this point, connect the electrical wire as shown in Figure 2, making sure that all wire connectors (D) are secured. If your outlet has a ground wire (green or bare copper), connect the fixture Ground Wire to it. Otherwise, connect the fixture Ground Wire directly to the crossbar using the Green Screw provided.
6. Slip the **Canopy (E)** up to the ceiling and tighten the set **Screw (F)** to secure the cord.
7. **Install the light bulb(H) in accordance with the fixture's specifications. DO NOT EXCEED THE MAXIMUM WATTAGE RATING! (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!)**
8. Your installation is now complete. Return power to the junction box and test the fixture.

IMPORTANT: FIXTURE SHOULD BE INSTALLED BY A QUALIFIED ELECTRICIAN TO ENSURE PROPER WIRING AND INSTALLATION.

