

Assembly Instructions: 3184-LP (Teagan)

IMPORTANT:


- ALL INSTALLATION WORK SHOULD BE DONE BY ACCREDITED PROFESSIONAL.
- SHUT OFF POWER SUPPLY AT FUSE OR CIRCUIT BREAKER!
- USE ONLY THE SPECIFIED BULBS. DO NOT EXCEED THE MAXIMUM WATTAGE!

For Customer Service, please contact the place of purchase.

PREPARING FOR INSTALLATION

Remove all of the contents from the carton. See the important notes above. Shut off the power at the circuit breaker and completely remove the old fixture from the ceiling, including the old mounting strap.

1. Take the mounting strap assembly from the parts bag. Mounting strap (B) contains several threaded holes. Two sets of mounting screws (A) should be attached to mounting strap (B). You may need to tighten nuts (C) which hold mounting screws (A) in place. Mounting screws (A) are long, please test the canopy (I) against the mounting strap to see how far you should insert the screws.
2. Pull the house wires through the center of mounting strap (B). Place mounting strap (B) over the junction box so that mounting screws (A) are in alignment with the hole locations on the fixture's canopy (I). Secure mounting strap (B) to the junction box with mounting screws (D) and a screwdriver. Tighten the screws securely.
3. Rods (L) are on the fixture's wires. Measure to determine the correct number of rods needed for proper hanging height. To lengthen the fixture, you can contact the place of purchase to order additional rods. To shorten the fixture, remove excess rods. Pull the wires taut before threading rods (L) together. Thread bottom rods (L) onto nipple (M) of the fixture's body. Twist the top rods (L) into the threads of each swivel post (J) and tighten thumb screws to secure.
4. Use spacers (H), washers (G), and hex nuts (F) to secure swivel posts (J) to canopy (I). Pull the fixture's wires through one of swivel posts (J) and through canopy (I).



CONNECTING THE WIRES


5. Have an assistant support the weight of the fixture while completing the wiring. Cut away excess wire leaving 8 to 10 inches of excess wire. Attach the fixture's wires to the house wires which were pulled earlier from the junction box through the mounting strap (A). Connect black to black (or smooth); white to white (or ribbed); ground to ground (green or copper). Twist the ends of the wire pairs together, and then twist on a wire connector. Make sure all twists are in the same direction. If there is no ground wire (green or copper) coming from the junction box, locate ground screw (E) on the mounting strap and wrap the fixture's ground wire around the green ground screw (E). Use a screwdriver to secure ground screw (E) onto the mounting bracket. Tuck all wires neatly into the junction box.

FINISHING THE INSTALLATION


6. As shown in the figure, use screws (U) to attach the wooden frame (P), lamp holder (N), and rod (Q) together. Lift wooden frame (T) to the bottom of rod (Q), then use screws (U) to tighten and secure at each of the corners of the fixture.
7. Place the fixture's canopy (I) over mounting screws (A) so that mounting screws (A) protrude through the holes in canopy (I). Thread deco nuts (K) onto the exposed threads of mounting screws (A). Screw socket covers (R) over the exposed sockets.

Install light bulbs (not provided) in accordance with the fixture's specifications. Do not exceed the maximum recommended wattage.

Your installation is now complete. Turn on the power and test the fixture.



How to Identify the Fixture's Wires		
Hot	Neutral	Ground
Smooth	Ribbed	Bare Metal, Green, or Green Inner Thread
Black	White	
Black Inner Thread	White Inner Thread	Thread



CLEANING TIPS

Treat the fixture gently! Regular cleaning will reduce the need for deep cleaning. For regular cleaning, turn off the light and wipe down the fixture with a clean lint-free cotton or microfiber cloth. Never spray cleaner directly onto the fixture.

